


#91850
 Replacement WF style box, front switches, with #85350 board



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	NS5461	Nut	4
2	NS5493	Lock washer	4
3	91887	90 degree conduit elbow	1
4	NS10480	Stainless takeoff box	1
5	NS5663	1/4"OD X 1/4"L X #6 Nylon round spacer	4
6	85350	Board	1
7	NS5662	Nut for board	4
8	91821	Blue label for front switch box	1
9	85352	LED bulb	1
10	91840	Red lens assembly	1
11	91841	Red lens	1
12	91835	Heavy duty toggle switch	1
13	91838	Water tight toggle switch cover	1
14	91830	Push button	1
15	91831	Push button cover	1
16	NS5520	Screw for cover	4
17	NS5481	Washer	4