


#91851
 Replacement WF style box, side switches, with #85350 board



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	NS5520	Screw for lid	4
2	NS5481	Washer for lid	4
3	NS5662	Nut for board	4
4	85350	Board	1
5	NS5663	1/4"OD X 1/4"L X #6 Nylon round spacer	4
6	NS10310	Stainless steel WF style takeoff box	1
7	NS5493	Lock washer	4
8	NS5461	Nut	4
9	92561	Cord grip, PG9	3
10	91823	Label	1
11	85352	LED bulb	1
12	91840	Red lens assembly	1
13	91841	Red lens	1
14	91838	Water tight toggle switch cover	1
15	91835	Heavy duty toggle switch	1
16	91831	Push button cover	1
17	91830	Push button	1