



# ALLFLEX DETACHERS




- Reliable automatic performance
- Handles slow letdown cows automatically
- Consistent milking every time
- Minimizes over-milking and under-milking
- Smooth, gentle detaching action
- Vacuum operated

- See through canisters let you know when a cow is milking
- Fast, positive, in place wash-up
- Low Maintenance. Easy Maintenance
- Adaptability that pays off
- Compatible with existing claws
- Counterweight adjusts take-off times




## HOW IT WORKS, STEP BY STEP




**1.** Milker pulls "trip" cord which sets valve in "milk" position releasing cylinder vacuum to allow claw attachment




**2.** Claw is attached, built-in delay waits for any slow letdown. Sensor will self-activate into automatic phase




**3.** Canister tips down as milk weight increases. Second letdowns are handled during this automatic phase.



**4.** Milk flow decreases to the take off time you preset. Counterweight pivots canister up to off position



**5.** Positive vacuum shut-off occurs when canister reaches off position. Claw then gently detaches from cow.



**6.** Cow is milked out. Vacuum is on at cylinder, claw is retracted. Detacher is ready for next cow.

# The Allflex Automatic Detacher. So Simple it Works. Time after Time.



Visit our Website at:  
[www.ezmilking.com](http://www.ezmilking.com)

**E-Zee NuPulse**  
4904 Triangle Street, Ste. A  
McFarland, WI 53558  
Tel: 800-233-6878  
Fax: 608-838-2221  
Email: [info@ezmilking.com](mailto:info@ezmilking.com)